




GLASS:





IMPORTANT

To ensure equipment safety you must carefully follow the instructions below. This leaflet must be kept handy by personnel entrusted with all ordinary and extraordinary maintenance. • Before any installation or maintenance operation on the bulb, make sure it is disconnected from power. • Fit the correct bulbs, according to the type and power indicated on the lamp data label. • Make sure the lamp technical features are compatible with the use you are going to make of it. • Should you have any doubt, refer to the dealer or ask an electrician. • When connecting to the mains, fallow the correct colour code far power cables: (N) blue, (L) brown or black and, only far class I equipment, (T) yellow/green. • When lamps are to be fitted to the wall directly through their ceramic parts, fasten the fixing screws lightly, to avoid breaking the ceramic. • To clean the lamp on the outside, use a soft cloth, possibly wet. Do not use solvents or abrasive products. No liquid must get in contact with the lamp interior parts. • Do not touch the equipment with dirty hands.



= The equipment at the end of its life must be collected separately from other waste