

Installation of Single Sided Fabric Light Boxes

The package contains:

- 1 assembled light box. Large sizes may come in two or more sections, unassembled
- 1 set of "Z" clips (optional)
- 1 set of hanging hardware (optional)
- 1 printed fabric (image provided by customer)
- 1 power supply & cord


1. A single sided fabric light box has LEDs on a back plate. The light box is back-lit, with a bright and even light.



2. Large light boxes may come in two or more sections. Connect the wiring with quick connectors, and connect the sections of the frame with provided flat connectors.





3. After assembling the frame, screw the frame to the wall using the holes on the back plate.



4. Alternatively, a set of “Z” clips can be used to hang the frame. The “Z” clip set comes in 2 parts: one is attached to the light box, and the other is screwed to the wall.



5. If ordered with hanging hardware, follow the instruction below:



1. To install, push the Hanging Cable into the Locking Piece on the lightbox and on the ceiling
2. To release the Hanging Cable, push the Locking Piece in, and pull the Hanging Cable out
3. To level the lightbox, push the Hanging Cable in, or release it, on both sides till the desired level is achieved

6. Insert the silicon rubber at the edge of the fabric into slots on the frame. Start from one corner, stretching the fabric as you go all around the frame.

Use a flat head screwdriver to help with last corner



7. Plug in the female connector on the light box to the male connector on the power supply.

